

DANCOVER[®]



Manual
for
Bouncy Castles

User Instruction

Congratulations on your new inflatable product purchase! Please read all instructions carefully before use.

Precautions

- Ensure electrical source is safe and stable before operation.
- Keep children away from blower. Do not insert fingers, toes, etc into the blower, or it may cause injury. Do not insert foreign objects into the blower. This will cause damage.
- Do not bring sharp objects into play area.
- Do not eat in play area.
- Do not smoke in play area.
- Keep product away from fire and heat.
- In case of blower malfunction, tighten blower vent and evacuate play area immediately.
- Do not use in rain, strong wind or extreme weather conditions.
- Observe precautions on product WARNING LABEL at all times.

STEP2: Setup

- Unroll product evenly across smooth, flat, debris-free surface. Connect blower(s) to inlet, and tie. Anchor the blower to the ground using the stakes provided.
- Plug in and start blower.
- If your item uses multiple blowers, connect all blowers to their inlets. Make sure all blowers are powered off (blower models with switch). Plug in all blowers, then switch them on one-at-a-time at 20 second intervals.
- Once inflated, anchor the inflatable product to the ground using the stakes provided.

STEP3: Disassembly

- Ensure that all the players have left play area.
- Remove any loose articles or debris from play area.
- Turn off, and unplug blower.
- Once product is fully deflated, fold & store in cool, dry area.

STEP4: Maintenance & Repairs

- Always keep products clean to protect the seams and surface.
- Regularly inspect seams and play surface for any necessary repair. Slight damage caused by nature or man-made factors can be repaired with the repair kit provided.
- To repair, deflate the product thoroughly, and ensure surface is dry. Cut patches to sizes suitable for repair. Apply glue on both the repair patches, and the damaged surface.
Allow the glue to air-dry for 30 seconds before adhering the patch to the play surface.
Allow to dry for at least 4 hours before use.

NOTE:

- Maximum weight of user: 100lbs each. _____

Blower Operating Instruction

THIS INSTRUCTION IS IMPORTANT FOR SAFETY
PLEASE READ AND SAVS THESE INSTRUCTIONS.

WARNING

1. This blower is not intended for use by children, adult operation and supervision must be required. The blower should never be left unattended when plug in.
2. To prevent electric shock, do not drop unit into water, do not expose to rain, never plug in or. Unplug the appliance with wet hands or while standing in water.
3. Avoid sands, small rocks and other small objects being sucked in the blower.
4. To avoid risk of injury, do not direct stream of air at face or body.
5. To reduce the risk of fire or electric shock, do not use this product with any solid-state speed control device.
6. If the power cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.

CAUTION

1. The blower is a high volume fan, and is capable of moving lots of air very quickly.
2. Check the blower before every use. Make sure there is no damage of blower before operating.
3. Fix the blower when necessary.

OPERATING

1. Plug the blower into a suitable voltage power, turn on motor switch, then so that it can then be used.
2. Turn off motor switch and unplug the blower after use.
3. The blower supply should be disconnected if the blower needs to be transported or removed

MAINTENANCE

1. To keep the blower clean you can use a dry cloth of a cloth wetted with a neutral solution or water to wipe the surface of the blower.
2. Never clean the blower with water.
3. Unplug and store at a fry indoor place unreachable for children, when not in use.

DISPOSAL

Do not dispose this product as unstored municipal waste. Collection of such waste separately for special treatment is necessary.

Contact information

Head office:

Dancover A/S
Nordre Strandvej 119 G
3150 Hellebæk
Denmark

For more information
please visit:
www.dancovershop.com

National contact

Denmark: 70 26 76 20
denmark@dancover.com

UK: 020 8099 7570
uk@dancover.com

Germany: 041 0266 7040
germany@dancover.com

France: 0975 181 800
france@dancover.com

Sweden: 040 233 262
sverige@dancover.com

Finland: 0 931 581 720
suomi@dancover.com

Poland: 22 300 8602
polska@dancover.com

Luxembourg: +49 041 0266 7040
luxembourg@dancover.com

Portugal: 308 800 899
portugal@dancover.com

Spain: 911 436 828
espana@dancover.com

Italy: 02 479 21 198
italia@dancover.com

Switzerland: 0840 000125
schweiz@dancover.com

Austria: 0662 626935
austria@dancover.com

Norway: 231 00 690
norge@dancover.com

Nederland: 0 858 880 524
nederland@dancover.com

Ireland: 0 151 33 003
ireland@dancover.com

Belgium: 0 28 08 08 09
belgique@dancover.com